

De-Winterizing Shaver Cabin (arrival) revised 11/24/21

(These notes accompany a newly revised YouTube video in case you need more of a visual aid.)



1. Go to Master Bath. Look under LEFT Sink and CONFIRM that the RED/BLUE valve handles are in the 3:30 position. If you don't do this step, the water will be gushing out of the drain line on the side of the house!



2. Now you can turn ON the water valve in the large, white PVC cylinder by the road at the front of the driveway. Use your legs to keep the cylinder in place while pulling the top off as it can come up from ground. Note: Sometimes it will be buried under snow, and the cap will be frozen. Just heat some water in microwave and pour on cap.

3. Return inside and VERIFY water has returned to sinks, toilets, etc.

4. YOUR WORK IS COMPLETE :)